



Meyer, S.; Wiese, B.; Hort, N.; Willumeit-Römer, R.:

Electrical resistivity testing.

In: International Intelligent Materials 2022. Kiel (DEU),
29.06.2022 – 01.07.2022.

Electrical resistivity testing


Sebastian Meyer, Björn Wiese, Norbert Hort, Regine Willumeit-Römer
Institute of Metallic Biomaterials



Objectives

- Quantification of the material strength of material states of the Mg-Ag system
- Development of a combined model for attribution and evaluation of the resistivity
- Design and establish a robust quality testing methods for tailorable material properties

Goal: Attribution of the electrical resistivity to the microstructure and properties




Four point probe resistivity measurement is used as a non-destructive, fast and simple method suitable for large scale quality control.

Material strength is a multiscale property composed of multiple microstructural aspects. By combining **solid solution hardening** and **dislocation hardening** the electric properties can depict the mechanical strength.

First principle approach

Matthiesen rule describes the resistivity as the sum of all intrinsic and temperature dependent properties:



Alloy composition

Alloying elements perturb the electron flow in the magnesium lattice and cause scattering. For dilute concentrations the resistivity increases linearly.


Elements

specific Nordheim constant C

Concentration

$$\rho(x) = C \cdot x [\text{at.}\%]$$

Mg alloying element	C [nΩm/at.%]
Ag	6.8
Zn	7.8
Al	17.0
Gd	86.0



Solid solution hardening


Dissolved foreign atoms also act as an obstacle to dislocation movements during plastic deformation. The strength increases with concentration approx. linearly.

Solid solution hardening


69 MPa/at.% Ag

Resistivity sensitivity

10 MPa/nΩm



Crystal characterization



With increasing plastic strain, the concentration of crystal defects such as dislocations increases.

True strain

$$\rho(\varepsilon) = k \cdot \varepsilon$$

Element	k [nΩm]
Mg	8.9

S. Meyer. et al. *Scr. Mater.* 215, 114712 (2022)

Work hardening

The material strength is increased by dislocation pile ups, which impede their movement and further plastic deformation

strain	R_{tm}
0	226
0.23	290
0.46	375

Work hardening

324 MPa/true strain

Resistivity sensitivity


36 MPa/nΩm

Attribution and Application

- In quality control, the alloy concentration can be checked in a known system, especially accurate with elements of high Nordheim constants.

- Quantitatively, work hardening (36 MPa/nΩm) has greater impact on resistivity, in the Mg-Ag system than solid solution hardening (10 MPa/nΩm).

- The resistivity evolution can be used to determine suitable heat treatments. An example is shown in the right diagram. The strength and the recrystallization state can be calculated and adjusted.



S. Meyer. et al. *Scr. Mater.* 215, 114712 (2022)

